

Installation Instructions

Parts included

Complete Handy Spray kit

Sealing Tape

Mounting Bracket

Parts Needed. Optional

Flexible Tank Water Line if current Water Line is stiff metal

Before beginning installation please assemble Handy Spray kit by inserting attached black rubber washer inside hose connector and screwing on spray wand on top.



Step 1

Turn off water supply by turning the flush tank shut-off valve. Flush to make sure flush tank is empty and water has stopped filling.



Step 2

Unscrew the connector hose from under the tank. Screw on Handy Spray connector between tank and supply line. (Use sealing tape)

If existing flush tank hose is stiff brass replace with a flexible hose



Step 3

Screw on the supply line under Handy Spray connector and tighten. (use sealing tape)

Turn on water and check for drips. Hand tighten as necessary.

Holder can be screwed on to wall or hung on side of flush tank.

Safety Note: Turn off sprayer using the slide switch attached to connector after each use.